STETHOSET RECEIVER

INSTRUCTIONS FOR USE



If you experience any problems with your receiver, please notify a member of staff and we will endeavour to rectify the difficulty.

This receiver is worn like a stethoscope and has three channels.

Channel 1: SHOW RELAY

Channel 2: AUDIO DESCRIPTION ONLY

(when it is being offered for certain performances)

Channel ∞: SHOW RELAY + AUDIO DESCRIPTION (when it is being offered for certain performances)

How to Use:

In order that the receiver can work correctly, please make sure that the volume control wheel is on the right hand side of the unit.

Turning the wheel to the right will switch the receiver on and increase the volume to the desired level.

The channel switch is on the left hand side of the unit. For channel 1, move the switch once to the left; for channel 2, move the switch twice to the left; for channel ∞ the switch needs to be moved to the far right.

